

Goal Images



Goal stored



Goal after being folded



Anchoring points when goal is assembled



Hook and loop straps for securing back bar when stored

Multi-goal sizes



366 x 183 cm  
12 x 6 ft



366 x 122 cm  
12 x 4 ft  
Lay the goal on its front



Remove the centre section from the crossbar and the back bar.  
244 x 183 cm  
8 x 6 ft



Lay the goal on its front.  
244 x 122 cm  
8 x 4 ft

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY


Assembly and Safety Instructions

IMPORTANT SAFETY INSTRUCTIONS

- 1. Always inspect the goal post and net for defects before use and replace damaged parts.
- 2. Do not use the goal with faulty parts.
- 3. The goal must always be secured to the ground. Weights to be used on hard surfaces, ground anchors on grass.
- 4. Never climb on the net or goal frame.
- 5. The goal must never be used without the net fitted.
- 6. Please adhere to the safety instructions at all times. Refer to the Football Association website ([www.thefa.com](http://www.thefa.com)) and British Standards for the recommended safety procedures.
- 7. When the goal is not being used, dismantle and store in a secure area.
- 8. This goal has been independently tested and complies with **EN 16579:2018+AC:2019**.
- 9. Warning. Not suitable for children under 3 years old due to small parts i.e. quick clips "Choking hazard" and length of cord "Strangulation hazard".
- 10. It is recommended that the goal is assembled by an adult.



**Routine visual check**  
A routine visual check should be carried out before each use.  
The routine visual inspection enables the identification of obvious hazards that can result from vandalism, misuse or general deterioration.  
Examples of visual inspection:  
— damage to the goal frame  
— lack of / insufficient anchorage or stability equipment  
— damaged or missing fixings  
— damaged nets / missing net fixings  
— correct attachments of net to the goal frame

**Method of anchoring**  
Arrows indicating anchoring points and anchors to be inserted at 45 degrees.



SAMBA


Fold-A-Goal  
With locking system



Part No	Qty	Length - cm	Length - in
1	2	117	46
2	2	110	43
3	6	117	46
4	2	51	20
5	6	-	-
7	4	102	40
9	2	-	-
10	6	-	-
12	4	-	-
13	1	-	-
14	40	-	-


Assemble following the steps below

Before starting assembly lay all the components out on the ground and check they correspond with the parts list.




Step 1

Assemble the base with the part numbers shown, sliding and locking the parts together.



Step 5


Fit the uprights to the base.




Step 6

Fit the crossbar to the uprights.

Step 7  
Fit the tension bars to the back of the goal,  
**ALWAYS FIT IN THE TOP FIRST.**



Step 8  
Fit the net, **with colour cord to the top**. Start by fitting the net to the top corners first, wrapping the net round the posts and fixing with the clips.



Step 2


Assemble the crossbar with the part numbers shown, sliding and locking the parts together.

Step 3

Assemble the 2 uprights with the part numbers shown, sliding and locking the parts together.

Step 4


Assemble the tension bars with the part numbers shown, sliding and locking the parts together.




Step 9

Securely anchor the goal to the ground using the 4 grass anchors provided, use the arrows for guidance. On hard surfaces use 3 × 18 kg / 39.6 lb weights as shown.

Samba Fold-A-Goal  
How to fold the goal




1. Release net from base bar and then remove base bar.



View showing goal folded  
(Net not shown for clarity).

NOTE! Base bar can be fastened to the bottom of the goal with the Velcro straps provided for storage.



2. Press the button in at the top corners at each side of the goal and fold the sides in.