











Assembly Instructions and Safety Procedures


COMPONENT	No	Qty	Size
	1	2	43"
	2	2	32"
	3	4	33.5"
	5	2	
	7	4	28"
	9	2	
	10	6	
	12	2	
NET	13	1	
 QUICK CLIPS	14	1 bag	20

Assembly sequence: (See overleaf for images)

- Always check the goal post and net for defects before use and replace damaged parts.
- It is recommended that the goal is assembled by an adult.
- Assemble the base first.
- Fit the uprights.
- Assemble the crossbar.
- Fit the crossbar.
- Assemble the tension bars, 2 item 7's and 1 item 9.
- Fit the tension bar assembly to the goal. IT IS IMPORTANT that the tension bar is fitted to the top of the goal first then bend down and fit in the large hole in the base.
- Fit the net by wrapping the net round the tube and clipping on the inside. Coloured cord to the TOP of the goal.
- Ensure the posts are upright and the crossbar is level before securing to the ground with the anchors.



Please note: Not all goals are supplied with coloured corners and connectors



Safety Procedures

Safety:

- Always check the goal post and net for defects before use and replace damaged parts.
- Do not use the goal with faulty parts.
- The goal must always be secured to the ground. Weights on hard surfaces, ground anchors on grass.
- Never climb on the net or frame.
- The goal must never be used without the net fitted.

Information:

- This goal has been independently tested and complies to BS EN Parts 1 & 3 safety standard.
- Warning. Not suitable for children under 3 years old due to small parts i.e. quick clips "Chocking hazard" and length of cord "Strangulation hazard".
- It is recommended that the goal is assembled by an adult .